

# KimaAir OUTSIDE/IN Vent

Effective roof space ventilation - fitted from the outside on new builds



Mark and cut a hole in the underlay



Squeeze the underpart of the kima-Air outside/in and push through the Hole, so that the underlay will be Between the under part (in) and the Grill (out)



Mount the grill, whilst holding onto the strip



Press the grill against the underlay pull the strip to tighten



The KimaAir Outside/in is now installed



Cut the strip off approx. 1 cm above the grill.



Image shows finished installation, as seen from the roof

KimaAir outside/in vent is the new way of protecting your roof space against excessive condensation

KimaAir outside/in is installed from the outside of the roof space.

- For pitched roof underlays.
- Simple, one-person installation.
- Fitted from outside the roof.
- Ventilation area: 56 cm<sup>2</sup>.
- Material: Polypropylene.
- Can be used with all types of underlay from 0,2 mm - 25 mm.
- Installed between the rafters



Kima Roof Accesories ApS  
Grindsted Landevej 69, Eg, 7200 Grindsted, Denmark tel: +45 7533 0800  
Email: [mail@kimarroof.dk](mailto:mail@kimarroof.dk) webpage: [www.kimarroof.dk](http://www.kimarroof.dk)